Image: state stat

- The fast "Spot-on" synchroniser
- LEAD and/or LAG synchronising facility
- Breaker closing time compensation
- Dead-bus facility
- "Easy view" status presentation
- Generator speed control (relays)
- Generator speed reference (analogue output)
- System status output

# **Specifications**

| Monitored Voltage<br>Input:   | 25-500VAC, 40-70Hz   |  |
|---|--|--|
| Aux. Supply:  | AC: 100-120, 200-240, 380-415,<br>or 440-460VAC, 40-70Hz<br>(Fuse 0,5A)<br>DC: 24, 48 or 110-250VDC<br>(Fuse 2A)   |  |
| Voltage Tolerance:  | ± 10%  |  |
| Contact Rating:   | AC: 100VA - 250V/2A max.<br>DC: 50W - 100V/1A max.   |  |
| Adjustments:<br>Frequency diff:<br>CB closing time:<br>High voltage:<br>Low voltage:<br>Pulse rate:<br>Pulse vidth:<br>*Analogue output:<br>*Optional output: | 0,1-2Hz<br>30-300mS<br>2-15% of net voltage<br>2-15% of net voltage<br>12-60 pr min<br>120mS to 1,6secs<br>-10/0/+10mADC = -5/0/+5Hz<br>max 400ohm<br>-3/0/+3VDC (-3/0/+3Hz) |  |
|   | min 50kohm<br>*Only active when Sync. mode is<br>selected  |  |
| Temperature:  | -20 to +70°C   |  |
| Weight:   | 0.7kgs   |  |
| Front protection:   | IP52 (IP54 & IP65 optional)  |  |
|   |  |  |

Unit meets IEC60092-504 and relevant environmental

and EMC tests specified in IEC60068/60092 and

IEC61000/60533 respectively, to comply with

Megacon is the inventor of the original, now industry

standard "rotating" LED display, and a trendsetter in

Classification Societies requirements.

modern synchronisation control.

## Description

The digitally controlled KSQ104EJD42x provides both visual presentation of voltage differential and relative speed and phase angle relationship and speed control output signals necessary to achieve fast automatic "Spot-on" synchronising between two systems. When used as dead-bus coupler the CB close relay will energise when bus is "dead" and the digital input (dead-bus enable) is closed (mode 4 to 6, see page 2).

KSQ104EJD42x

Its many important features contribute to make KSQ104EJD42x simply the best choice available for synchronising in any automatic generator control system (PM-system).

**KSQ104EJD42A** as standard is powered from the montored voltage on terminal 3 & 4. **KSQ104EJD42B** have separate auxiliary supply on terminal 19 & 20.

### Applications

KSQ104EJD42x is used for both single and three phase systems. Any two phases (or phase-neutral) can be used for synchronising as long as they are the same two phases on both sides of the breaker. The synchroniser is rated for continuous operation and can be left connected when not in use.

### Synchronising modes

To adapt the functionality of KSQ104EJD42x to any specific application, the direction of approach to synchronising (LEAD, LAG or NEUTRAL) can be selected as required:

LEAD (incomer faster than bus) LAG (incomer slower than bus) NEUTRAL (will synchronise in both directions)

LEAD is generally the preferred mode. The synchronising relay will then operate when the frequency of the incomer is slightly HIGHER than the bus frequency. This is to avoid motoring of the incomer (entering reverse power condition) after the breaker is closed.

The rotary LED display and the direction of the yellow arrows indicate the incomer's speed relative to the bus. The rotary display is not lit if frequency difference between systems exceeds 5Hz.

### Speed control

The raise/lower relays pulses the fuel control governor motor, or an interfacing MXR845x electronic potentiometer. Pulse length and rate of the speed control relays are adjusted on the rear of the unit to suit the dynamic response of any engine regulator. The speed control has a P/I (proportional/integral) characteristic, with a dynamically controlled dead zone.

Alternatively the linear analogue -10/0/+10mA output signal can be used as speed reference to a generator controller, with polarity and amplitude proportional to frequency difference between the two systems when synchronising mode is selected.

### System status:

KSQ104EJD42x is fitted with a system status relay. When power is ok and unit is working correctly the relay activates. It will release on alarm or when unit is not powered.

Normal operation Alarm condition/unpowered : Closed contact : Open contact

Norway Denmark United Kingdom

# megacon

# www.megacon.com

LECTRONIC CONTROL AND INSTRUMENTATION

REF: Datasheet.KSQ104EJD42 - REV: 1.06/07.2021 © All rights reserved to Megacon Megacon reserves the right to make any changes to the information at any time

# "SPOT-ON" AUTOMATIC SYNCHRONISER WITH DEAD-BUS

#### Connection Busbar L1 L2 L3 N KSQ104EJD42x 1 11 CB close 12 2 Raise 13 14 Lower 15 3 16 4 (Closed Systen status when ok 17 Generator 18 19 Separate 5 LEAD Aux. Supply 20 (Only on KSQ104EJD42B) Mode 6 LAG 7 Dead-bus enable 8 9 21 Analogue NOTE Output Select a synchronising mode 22 10 before using the unit

## **Operation Modes**

| Mode 1 | LEAD               |         |
|--------|--------------------|---------|
| Mode 2 | LAG                |         |
| Mode 3 | NEUTRAL            | 5 6 7 8 |
| Mode 4 | LEAD + DEAD BUS    | 5 6 7 8 |
| Mode 5 | LAG + DEAD BUS     | 5 6 7 8 |
| Mode 6 | NEUTRAL + DEAD BUS | 5 6 7 8 |

System<sup>"</sup>P"

"Spot-on" synchronising

LEAD direction

Fig.1

tin

KSQ104EJD42x

System<sup>"</sup>P"

"Spot-on" synchronising

LAG direction

Fig.2

# **Description**

### "SPOT ON" synchronisation - CB closing time compensation

The dynamically controlled CB closing time compensation provides a SMOOTH synchronising, avoiding that the engine/generator couplings are exposed to excessive torque forces. Is FAST synchronisation the priority, an accurate "SPOT-ON" synchronising will still be maintained even with a high frequency difference between the power sources.

### The System "P" synchronising principle

The relay closure is initiated at "T" when the breaker coil is energised and finalises at "P", assuring a precise "12 o'clock" synchronisation (figs 1 and 2). Allowed frequency difference is adjustable between 0.1Hz to 2Hz.

Typical setting for smooth synchronising is 0,2Hz. The angle "a" varies according to the calculated frequency difference between the two systems. The synchroniser operation and accuracy is not influenced by distorted voltage waveform or harmonics.

### Synchronisation

Green lamps indicate voltage presence on reference source (BUS PWR, only when generator is powered) and incoming generator (GEN PWR). Green lamps also indicate that voltage and frequency differential between the two systems are within the limits. The synchronising relay will close when above conditions are achieved.

A green lamp (CB close) indicates the closing command to the breaker. Frequency difference and voltage limits, circuit breaker closing time, speed control relays pulse length/rate and synchronising mode are user settable on unit rear.

Note: The CB Close LED will flash when unit is ready for synchronising, but inhibit input is open or synchronising mode is not selected.

## **Dimensions**



# **Operation Dead-Bus**

| Gen. | Bus  | Dead-Bus Enable | Operation     |
|------|------|-----------------|---------------|
| Dead | Live | Closed          | No CB close   |
| Live | Dead | Closed          | CB Close      |
| Dead | Dead | Closed          | No CB close   |
| Live | Live | N/A             | Normal Synch. |



ORDERING INFORMATION KSQ104EJD42B Product type Auxiliary supply 110VDC : 230VAC Network voltage



Norway Denmark **United Kingdom** 

# eggeon

www.megacon.com

ELECTRONIC CONTRO L AND INSTRUMENTATION